

Experiment Title

Aim: Study of LAN Topology, network Devices, and Address configuration

Problem Statement

1. Draw the network Topology:
- Identify and draw the Lan topology of & clearly label all components.

Sol → The collage campus network observed this Study consists of :-

- Layer 3 core switches in the server room.
- Managed by PoE switches
- Wireless Access point (AP)
- Ethernet Port in classroom & laboratories

Network Topology : Hybrid hierarchical topology which combines.

- ① Tree topology
- ② Extended star topology
- ③ Ring Topology (Server room)

The network hierarchical layer

- ① Core layer
- ② Distribution layer
- ③ Access layer

- Core layer ÷ Core layer contains server room and server room have firewall, Routers, 2-L3+ Switches Patch Rack, server, inverted etc.
- Distribution layer ÷ Distribution layer 4-switches

The four switches are -

- Main building → R₇ (Room no 213, 2nd Floor)
- Main building → R₁ (Room no 301, 2nd Floor)
- Main building → R₆ (Room no 113, 1st Floor)
- Main building → R₂ (Room no 201, 2nd Floor)

→ This 4-switches contains ÷

→ 18 Port Gigabit Easy smart switches with 16-Port (TL-SG1218MP-E)

→ (SG2418XMP) → 24 Port Gigabit & 4 Port 10 GbE PoE+, L2+ managed switches 24 Port PoE+.

1. TP-Link TL-SG1218MP

- likely used for: CCTV camera, wifi access Point etc.
- 18 Port gigabit "Easy Smart Switch".
- 16 Port Support PoE+

② TP-Link Omada SG3428XMP

- Higher-end managed layer 2 switches.
- 24 PoE+ Port, uplinks, 10 Gbps
- Usually act as a main distribution for each floor.

Access layer : Access layer contain 3- switches, i.e.

1. Main building R₁ (Room no - 301)
2. Main building R₄ (Room no - 05)
3. Main building R₅ (Room no 18)


→ Every switches act as access layer which helps to provide network connectivity to all classroom, lab faculty room etc.

→ Access layer directly connect:

- ① ethernet Port
- ② wireless AP
- ③ Lab system
4. outdoor wireless.


Server room Architecture

Router



L2 + Switches

Topology




→ R₁, R₇, R₂, R₆ → Distribution layer

→ Server room → core layer

→ R₁, R₂, R₃, R₄, R₅, R₆, R₇ → Access layer.

Access Layer Switch (2nd Floor)



Microsoft Windows [Version 10.0.26200.8246]
(c) Microsoft Corporation. All rights reserved.

C:\Users\asus>ipconfig

wired connection

Windows IP Configuration

Ip address
using ipconfig

Ethernet adapter Ethernet:

Media State : Media disconnected
Connection-specific DNS Suffix . :

Ethernet adapter Ethernet 4:

Connection-specific DNS Suffix . :
Link-local IPv6 Address : fe80::1c58:9285:2343:ab1d%8
IPv4 Address. : 192.168.56.1
Subnet Mask : 255.255.255.0
Default Gateway :

Ethernet adapter Ethernet 5:

Connection-specific DNS Suffix . :
IPv6 Address. : 2409:40e4:b:62c6:a33f:4036:d440:cd7b
Temporary IPv6 Address. : 2409:40e4:b:62c6:1d84:290:91:e9ce
Link-local IPv6 Address : fe80::c6fa:27dc:aeb1:7d5f%57
IPv4 Address. : 10.108.64.136
Subnet Mask : 255.255.255.0
Default Gateway : fe80::2868:b6ff:fe40:c578%57
10.108.64.135

Wireless LAN adapter Local Area Connection* 1:

Media State : Media disconnected

Connection-specific DNS Suffix . : wireless connection

Wireless LAN adapter Local Area Connection* 2:

Media State : Media disconnected

Connection-specific DNS Suffix . :
Ip address
using ipconfig

Wireless LAN adapter Wi-Fi:

Connection-specific DNS Suffix . :

IPv6 Address. : 2409:40e4:114e:b3de:87d4:a230:a309:4989

Temporary IPv6 Address. : 2409:40e4:114e:b3de:7cce:2b94:8d25:be65

Link-local IPv6 Address : fe80::ac23:944b:300a:104d%9

IPv4 Address. : 10.175.38.127

Subnet Mask : 255.255.255.0

Default Gateway : fe80::cccc:5cff:fe1d:bcbe%9
10.175.38.181

C:\Users\asus> getmac

Mac address

Physical Address	Transport Name
E8-B0-C5-19-51-B8	\Device\Tcpip_{50CD253C-9DC9-4D65-99FC-BFEBA430418B}
CC-28-AA-17-45-B3	Media disconnected
0A-00-27-00-00-08	\Device\Tcpip_{4CBE8870-F434-419E-BD9F-99FDA7BB8E7A}
E8-B0-C5-19-51-BC	Media disconnected
00-FF-97-72-FC-FC	Media disconnected


C:\Users\asus>

Performance

Run new task




CPU
15% 1.29 GHz



Memory
7.4/15.6 GB (47%)



Disk 0 (C: D:)
SSD (NVMe)
2%




Ethernet
Ethernet 4
S: 0 R: 0 Kbps



Wi-Fi
Wi-Fi
S: 0.1 R: 10.4 Mbps




GPU 0
NVIDIA GeForce RTX...
1% (53 °C)



GPU 1
Intel(R) Iris(R) Xe Gra...
0%

Wi-Fi

Intel(R) Wi-Fi 6 AX201 160MHz



Send
80.0 Kbps

Receive
10.4 Mbps

Adapter name: Wi-Fi
SSID: cin>>"password"
Connection type: 802.11ac
IPv4 address: 10.175.38.127
IPv6 address: 2409:40e4:114e:b3de:87d4:a230:a309:4...
Signal strength:

Q DIFF b/w wired & wireless speed?

Sol

Wired network

- Faster communication
- Stable connection
- Low latency
- Dedicated Physical medium

Wireless network

- Slower communication
- Affected by distance / Interference.
- High latency
- Shared radio medium.

Q Role of Subnet mask in network?

- A subnet mask identifies the network portion & host portion of an IP address. It helps device determine whether another device belongs to the same network or different network.

• It is important for:

- (1) Network Segment
- (2) Efficient routing
- (3) Communication b/w devices.